

Make a folder in the MATLAB path and put in all the tek files from the zip.  
Then start MATLAB and try tek2012init. You might need to modify the code some.  
By hand you can go to tmtool and see the scope.

start tmtool

Hardware visa → scanf not there

Instrument object:Interface Oject: → right click create new interface obj and  
select device

Instrument driver:Matlab Inst. Drivers:tds2012 → right click to create device  
object using driver

Instrument Objects: Device Objects: Tek scope → connect;