



Quick Reference Guide

Product Type: OEMZL4 Step Motor Drive

The above product is in compliance with the requirements of directives

- 72/23/EEC Low Voltage Directive
- 93/68/EEC CE Marking Directive

Additional Information:


For complete user documentation, please refer to the Compumotor web site (www.compumotor.com) where User Guides can be found on-line or hard copies requested.

For questions, please contact:

Technical Assistance, Applications Engineering Department
 (e-mail tech_help@compumotor.com or call 800-358-9070 North America, 707-584-7558 International).

The following table describes which User Guides are applicable to the OEMZL4:

| Part Number | Title |
|--------------|---|
| 88-014027-01 | <u>ZETA4 User Guide</u> Note: All information contained within this user guide is applicable with the exception of the Active Damping feature. All references to this feature should be ignored. |
| 88-015920-01 | <u>ZETA4 Drive and ZETA6104 Indexer/Driver User Guide Addendum LVD Installation Instructions</u> Note: All information contained within this document is applicable to the OEMZL6104. |
| 88-015436-01 | <u>EMC Installation Guide</u> Note: Refer to the Step Motor Drives section of this document for applicable information |



OEMZL4 Stepper Drive

Compumotor Division
 Parker Hannifin Corporation
 p/n 88-018139-01 B
 September 1, 1999



